Telephone Recorder User manual



How to use:

Installation:

The Telephone recorder has two ports (line1 and line2), one port connects to the telephone main line,

and the other port connects to telephone | Playback: base line port, Connect it to power supply via Connect the recorder to computer using USB cable, check below diagram



LED light turn on red when connected to power supply, the recorder begins to recording the voice when pick up Setting Date and Time: telephone headset, LED light will flashing | Connect it to computer via USB cable, open one time per second.

the USB cable provided.

Please wait for few seconds, the computer will install the driver automatic. then the computer will pop up a removable disk logo. Open it up and there will be files for Audio and time.txt.

The recorded file is saved under the WAV folder, file format is .way. File format is "year - month - day - hour - minutesecond-recording number. Wav"

the U disk, at the root directory to create a file named "time, txt" and edit content:

2014-08-08 09:20:00 updated the content and save the files.

Take out the recorder from computer and connect it with power supply, it will updated the date and time, you can records a file to check it.

Troubleshooting:

When the storage space is insufficient, or the device on halt, the red light will flashing quickly, If you want to continue to use this recorder, delete the files or open the cover change a memory card, the device will working back.

Note:

A. Please check power supply is properly connected after installation.

B. Format the U disk if couldn't open the U disk . If LED flashing fast, SD card installed Error, please open the cover to reinstall the memory card.

ltem₽	Parameters₽
Audio Format₽	WAV ₽
Power adapter₽	5V 1A₽
Memory₽	8GB ₽
Bit rate: ₽	32kbps₽
Interface type.	USB₄³
Supporting	Windows
system₽	me/2000/xp/2003/vista/win7/win8,Mac
	10.4,Linux&

Warning:

Application: Please strictly abide relevant regulations and laws. This product should not be used for any illegal purposes. The user is fully responsible for its use.

Operating temperature: 0 – 40. Operating humidity: 20% - 80%, this product is not waterproof so don not get it wet or use it in a humid environment. Other matters: Do not use this product in strong magnetic or strong electric powered environments.